

ARCHLINE							
Sizing Chart							
EURO	US/AUS Women	US/AUS Men	US Kids	UK Women	UK Men	Length (CM)	Width (CM)
31			13			19.3	8.5
32			1			20.1	8.7
33			2.5			20.8	8.9
34			3.5			21.6	9.1
35	5		5	3.5		22.5	9.3
36	6			4.5		23.4	9.5
37	6.5			5		24.2	9.7
38	7.5			6		25	9.9
39	8.5	7		7	7.5	26	10.1
40	9	7.5		7.5	8	27	10.3
41	9.5	8		8	8.5	27.8	10.6
42	10	8.5		8.5	9	28.6	10.7
43	10.5	9		9	9.5	29.4	10.8
44	12	10.5		10.5	11	30.3	11
45		11.5			12	31.2	11.2
46		12.5			13	31.8	11.5
47		13			14	32.2	11.8

* This size chart applies to the ARCHLINE Flip Flops, Slippers and Orthotics Ranges.

Notes:

Every manufacturer has different specifications for their own sizes.

The fit may differ from other shoe brands. We have tried to get it to the most standard shoe fit possible.

We have created a sizing guide to help you select the most suitable fit.

We feel using Centimeters is the best comparative measure and will allow you to get the best fit for your feet.

All Measurements are from the longest and widest points of the shoe.

Things to consider when fitting your shoe:

Fit to Width BEFORE Length

Most of us have one foot that is larger than the other, so fit your shoe to your larger foot.

The ideal fit is when your foot fits within the boundaries (and not to the extreme edge)

How to Measure Your Foot

1. Make sure measurements are made standing up. This ensures your foot is at its biggest.
 - 2a. Use a ruler or piece of string to measure your foot at the widest and longest points.
 - 2b. Alternatively, carefully trace around your foot with a piece of paper and measure the outline.

